

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

MOUNTING LOCATION:

Right side of radio cavity

TOOLS REQUIRED:

Pry tool, Flat screwdriver

8mm socket and ratchet

Phillips screwdriver

Cutting Pliers tool

1/4 & 11/32 wrenches

HARDWARE INCLUDED:

(2) 8-32x1/2" hex screw [2H]

(2) 8-32 Nylok nut [2M]

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: **75116-402**

MFG: **ACURA**

MODELS & YEARS: **RSX 2002-06**
RSX & Type-S w/CD Changer 2002-06

STEP #1: With pry tool or flat screwdriver, locate (2) slots in cover with lighter/power outlet. Pry each side out just enough to unsnap clips on each side. Pull out the cover from the bottom, while pulling the top out as well to release (4) clips. Disconnect the power plug, and set aside.

STEP #2: With the ratchet and 8mm socket, remove (2) screws that hold the radio bracket on. These screws are vertical and back about 4". Reach in to behind the radio, and push the radio assembly out. Tilt radio assembly to release top clip left side, then work out the remaining (3) clips. You may need to assist removal of the clips with the pry tool or screwdriver. Disconnect the emergency flasher plug to allow access to the screw.

STEP #3: With Radio and Cubby Box: Remove (1) screw that holds the radio bracket to radio bezel. Place the InDash by PanaVise over the pin and screw hole and replace the screw. Reinstall the radio assembly and bottom cover

With Radio & CD Changer: Pull radio out enough to get the (4) radio bracket screws out with your Phillips screwdriver, or 8mm socket. Remove these (4) screws, and slide the radio and bracket apart about 2-3". Use cutting pliers to cut off the post that touches the right side flange of the radio bracket. Place InDash by PanaVise over the flange, and install the (2) supplied screws and locknuts, with the 1/4" and 11/32" wrenches. Slide the radio and bracket back in place, replace the (4) screws. Reinstall the radio assembly, and bottom cover.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Finished Install Picture on Radio & Cubby



Finished Install Picture w/ CD Changer



10-27-05