

# INDASH by PANAVISE®

I-75102-607

Page 1 of 2

## MOUNTING LOCATION:

Right side of Radio

## TOOLS REQUIRED:

8mm Nut Driver  
(4) Radio Removal Tools (DIN)  
Clean Shop Rag  
Flat Dash Tool  
T20 Torx Driver

## PARTS INCLUDED:

(1) S75102-607 Mount

### For A4, S4, & 2008+ TT start here:

STEP #1: With the Audi Radio removal tools ( Double DIN A4 -4 each), (Single DINA4-2 each) remove the radio enough to get at the right side radio screws. DO NOT disconnect the wires from the radio.

STEP #2: With the 8mm nut driver, remove one screw from the right top corner of the radio cavity. Place the hole of the InDash Mount over the screw hole, align the holes and reinstall the screw. Carefully install the radio back into place.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.

### For Q7 Start Here:

STEP #1: With hook tool, insert it into the out sides of the air vents. Insert into the (2) holes at the sides. Pull to release (2) clips located at the bottom sides of the assembly. Also there are (4) spring clips to release on top of the air vents. Use the flat plastic dash tool to get these clips to release these clips by inserting it between the air vent and the display bezel. Pry the vents down to help release these clips. Pull out the air vents and set on top of the dash.

STEP #2: With Radio Removal tools, remove the CD Changer and move it out of the way.

STEP #3: Place Indash by PanaVise Mount on flat spot behind CD Changer below where backwards screw is, and mark where to trim about 1/4"x3/4" slot into dash to allow mount to fit flush to dash. Use supplied screw Indash Mount up against the dash side. Tighten screw. Replace CD Changer while pushing mount to the right.

STEP #4: Replace air vents assembly.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.

## CELL PHONE & MEDIA MOUNT

### INSTALLATION INSTRUCTIONS

PART#: 75102-607

MFG: AUDI/VW

MODELS & YEARS:

AUDI-A3 06-13, A4 02-08, Q7 07-15

S4 04-08, A4 Cabrio 03-08, TT 08-14

VW- Beetle 12-14 (pg.2)

## \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



A3 Final Install Picture



A4 Final Install Picture



TT Final Install Picture



Q7 Final Install Picture



Q7 Mounting Location



Q7 Air Vent Removal Hole Location

08-15-14



# INDASH by PANAVISE®

I-75102-607

Page 2 of 2

## MOUNTING LOCATION:

Right side of Radio

## TOOLS REQUIRED:

8mm Nut Driver

(4) Radio Removal Tools (DIN)

Clean Shop Rag

Flat Dash Tool

T20 Torx Driver

## PARTS INCLUDED:

(1) S75102-607 Mount

## CELL PHONE & MEDIA MOUNT

### INSTALLATION INSTRUCTIONS

PART#: 75102-607

MFG: AUDI/VW

MODELS & YEARS:

AUDI-A3 06-13, A4 02-08, Q7 07-15

S4 04-08, A4 Cabrio 03-08, TT 08-14

VW- Beetle 12-14 (pg.2)

## \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

## For VW Beetle Start Here:

STEP #1: with Flat Dash Tool, remove the bezel that covers the climate control by insert it into the right side between the dash and the bezel and pry to release clip(s).

STEP #2: With T20 Torx Driver remove the right side climate control screw and loosen the (3) other screws that hold the climate control in place.

STEP #3: Place the Indash by PanaVise Mount behind screw and flange. Reinstall and tighten screws, starting with the (1) that holds the mount in place.



Climate Control bezel removed



InDash Mount installed showing screw location.

08-15-14

