

INDASH by PANAVISE®

75107-510

Page 1 of 1

MOUNTING LOCATION:
Right side of climate control CR

CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS

**** ADVISEMENT ****

TOOLS REQUIRED:

Dash Tool, Hook Tool

7mm Socket Driver

Phillips Screwdriver

PARTS INCLUDED:

(1)S75107-510 Mount, (1)S75002 TOP

(2) 8-32" Acorn Nuts

PART#: 75107-510

MFG: FORD

MODELS & YEARS:

Taurus 2010-2018

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: Open console door to allow access to the side panel bezel strip, that goes from the back of the console cubby to below the air vent to the right of the radio.

STEP #2: Remove the bezel strip, releasing (5) clips. To release the clip up by the air vent, insert Dash Tool in between the bezel and the air vent and pry up. Set bezel aside.

STEP #3: Place the InDash Mount bottom piece over the screw and pin holes. Replace the screw.

STEP #4: Replace the bezel strip starting at the top. Install the Top part of the mount (75002) with the (2) Acorn Nuts and 5/16" wrench.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Removal of the bezel strip



Removal of the bezel strip



InDash installed showing location



Mount installed on 13-16 Taurus



InDash installed showing location

09-22-2020

