

INDASH by PANAVISE®

I-751071201

Page 1 of 1

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Instrument panel screws



Do not cover this hole.
InDash placement and screw locations.

MOUNTING LOCATION:

Below center air vent (V B)

TOOLS REQUIRED:

9/32" socket driver

Hook tool

Ford DIN radio removal tool

Protected jaw pliers

3/32" drill bit & drill

HARDWARE INCLUDED:

(3) #8x9/16" Needle point screw [3A]

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 751071201

MFG: FORD

MODELS & YEARS:

**E-150,250,350,450 Van
2001-2008**

STEP #1: With 9/32" socket driver, remove (2) screws above the instrument panel. With Ford DIN radio removal tool, take out radio, disconnect plugs, and set aside. Pull headlight switch to on position. Take hook tool and pull on spring clip in slot on knob to remove. Use protected jaw pliers to unscrew the head light switch round bezel.

STEP #2: Set the parking bracke, turn on the ignition, **DO NOT START**, put shifter into 1st gear. Start by pulling bezel that goes from the right of the vent next to radio, all the way to the drivers door at the head lamp switch. There are (12) clips holding this bezel on. Disconnect any power outlet plugs. Tilt down steering column all the way if possible to assist in removal of the bezel. Set bezel aside.

STEP #3: Place the InDash by PanaVise Mount below the center air vent flush with the dash lines. (See picture)

Mark the hole locations. Drill pilot holes, and place InDash over the holes.

Install the (3) supplied screws making sure the InDash is flush with the dash.

Carefully tighten the (3) screws.

STEP #4: Reinstall large bezel, starting from the instrument panel, then the head light switch bezel and knob, and the radio.

**INSTALLATION IS NOW COMPLETE
ENJOY YOUR NEW INDASH by PANAVISE MOUNT**



Final Installation Picture

