

# INDASH by PANAVISE®

I-75112-308

Page 1 of 4

## MOUNTING LOCATION:

Right side of radio JR

## TOOLS REQUIRED:

- Hook tool
- 9/32" small socket & ratchet
- 5/16" open end wrench
- 10mm socket driver

## PARTS INCLUDED:

- (1) S7-1977 Mount
- (1)S7-1932 -75001 TOP W/
- (2)-O- 8/32" Acorn Nuts

## Start Here for Chevy Express :

STEP #1: With 10mm socket driver, remove the (4) bolts located (2) under the drivers knee pad, and (2) under the passengers knee pad. Remove each cover releasing (6) clips each and set aside.

STEP #2: Begin to remove the large bezel that goes from the left of the passenger air bag to the drivers door (11+) clips. Release the right side power outlet plug. Pull out just enough to get at the right side radio screw.

STEP #3: With 7mm socket driver remove one of the right side radio screws. Either will work. Place the InDash by PanaVise Mount over the screw hole, and replace the screw.

STEP #4: Insert the part B (w/studs) into the Part A so that you can read the logo and part number left to right. Install the (2) cap nuts supplied and tighten with the 5/16" open end wrench.

## CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#:75112-308

MFG: CHEVY/GMC/SATURN

MODELS & YEARS:

GMC Savana (G-Series) 2008-18 (pg.1)

CHEVY Express (G-Series) 2008-18 (pg.1)

Malibu 2008-12 (pg.2)

SATURN-Vue 2008-09(pg.3)

Traverse 09-12,13-16,BUICK-Enclave 13-17

GMC-Acadia 13-16,&Acadia Ltd 2017(pg.4)

NEW PICS AND UPDATE INSTRUCTIONS

## \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Passenger Knee Pad Removed



Driver Knee Pad Removal

INSTALLATION IS NOW COMPLETE  
ENJOY YOUR NEW INDASH by PANAVISE MOUNT



Finished Install on Express/Savana



Part A Installed on Express/Savana



01-30-19

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise InDash Applications List: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com

© 2019 PanaVise Products, Inc.

# INDASH by PANAVISE®

I-75112-308

Page 2 of 4

## MOUNTING LOCATION:

Right side of radio JR

## TOOLS REQUIRED:

- Hook tool/Dash tool
- 9/32" small socket & ratchet
- 5/16" open end wrench
- 10mm socket driver

## PARTS INCLUDED:

- (1) S7-1977 Mount
- (1) S7-1932 -75001 TOP W/
- (2)-O- 8/32" Acorn Nuts

## CELL PHONE & MEDIA MOUNT

### INSTALLATION INSTRUCTIONS

PART#:75112-308

MFG: CHEVY/GMC/SATURN

MODELS & YEARS:

GMC Savana (G-Series) 2008-18(pg.1)

CHEVY Express (G-Series) 2008-18(pg.1)

Malibu 2008-12 (pg.2)

SATURN-Vue 2008-09(pg.3)

Traverse 09-12,13-16,BUICK-Enclave 13-17

GMC-Acadia 13-16,&Acadia Ltd 2017(pg.4)

NEW PICS AND UPDATE INSTRUCTIONS

## \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

## Start Here for Chevy Malibu:

STEP #1: With hands lift up and back on the shifter bezel to release (4) clips. Tilt up and pull down to release (2) tabs from the top of the bezel, and set aside.

STEP #2: With 9/32(7mm) socket driver remove (2) screws below the climate control/radio bezel. Pull out the bezel which includes the dash wings to each side of the bezel releasing (3) clips on each side.

STEP #3: With dash tool, pry to release lower part of the air vent bezel to allow removal of the top of the climate control/radio U- shaped bezel which has both horizontal and vertical pins. Angle the bezel to release both pins at the same time.

STEP #4: Remove either 7mm screw to the right side of the radio and install the bottom A Part of the InDash by PanaVise Mount.

STEP #5: Insert the part B (w/studs) into the Part A so that you can read the logo and part number left to right. Install the (2) cap nuts supplied and tighten with the 5/16" open end wrench.



Removal of bezel around radio and climate control-wings

INSTALLATION IS NOW COMPLETE ENJOY YOUR NEW INDASH by PANAVISE MOUNT



Installation of InDash Mount

01-30-19



There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise InDash Applications List: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com

© 2019 PanaVise Products, Inc.

# INDASH by PANAVISE®

I-75112-308

Page 3 of 4

## MOUNTING LOCATION:

Right side of radio JR

## TOOLS REQUIRED:

Hook tool/Dash tool  
10mm wrench, File  
Phillips screwdriver

## PARTS INCLUDED:

(1) S7-1977 Mount  
(1) S7-1932 -75001 TOP W/  
(2) O- 8/32" Acorn Nuts

## CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 75112-308

MFG: CHEVY/GMC/SATURN

MODELS & YEARS:

GMC Savana (G-Series) 2008-18(pg.1)

CHEVY Express (G-Series) 2008-18(pg.1)

Malibu 2008-12 (pg.2)

SATURN-Vue 2008-09(pg.3)

Traverse 09-12,13-16,BUICK-Enclave 13-17

GMC-Acadia 13-16,&Acadia Ltd 2017(pg.4)

NEW PICS AND UPDATE INSTRUCTIONS

## \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

## Start Here for Saturn View :

STEP #1: Remove top of dash speaker cover bezel. With dash tool pry off speaker grill starting from the front releasing (3) plastic clips and (4) metal clips. Remove (4) speaker screws, and remove speaker to allow removal of bezel completely.

STEP #2: With hook tool, remove the cap from back of cubby. With Phillips screwdriver, remove the screw. With dash tool lift up on the back of shifter bezel to release (8) clips. This bezel includes to climate controls and emergency switches.

There are (4) clips around the shifter, and (4) clips around the climate control.

STEP #3: Remove the air vent bezel by prying out the right side with the dash tool by radio enough to get at clips below radio, push down to release (3) clips. Pry up side to release (2) clips on each side. Lift up on the bezel to release (2) more clips enough to get at the right side radio screw. Remove the screw with the 10mm wrench.

STEP #4: You may need to file down or remove the washer from the existing screw to allow screw to fit back in place. Place bottom of mount over screw hole and replace screw.

STEP #5: Replace bezels in reverse order. NOTE: To replace the radio bezel you may need to file off some bezel to allow bezel to fit into place, as the bezel is tight. Insert the part B (w/studs) into the Part A so that you can read the logo and part number left to right. Install the (2) cap nuts supplied and tighten with the 5/16" open end wrench.

INSTALLATION IS NOW COMPLETE, ENJOY YOUR NEW INDASH by PANAVISE MOUNT



Bezel Removal



Top Bezel Removal



Speaker screws



Installation of InDash Mount



Mounting screw

01-30-19



### \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Installation of bottom part

### MOUNTING LOCATION:

Upper or Lower  
Right side of radio JR

### TOOLS REQUIRED:

Hook tool/Dash tool  
10mm wrench, File  
Phillips screwdriver

### PARTS INCLUDED:

(1) S7-1977 Mount  
(1) S7-1932 -75001 TOP W/  
(2)-O- 8/32" Acorn Nuts

## CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#:75112-308

MFG: CHEVY/GMC/SATURN

### MODELS & YEARS:

GMC Savana (G-Series) 2008-18(pg.1)  
CHEVY Express (G-Series) 2008-18(pg.1)  
Malibu 2008-12 (pg.2)  
SATURN-Vue 2008-09(pg.3)

Traverse 09-12,13-16,BUICK-Enclave 13-17  
GMC-Acadia 13-16,&Acadia Ltd 2017(pg.4)  
NEW PICS AND UPDATE INSTRUCTIONS

### Start Here for CHEVY Traverse 09-12 :

STEP #1: With your hands, pull at the side of the radio/climate control bezel to release (9) total clips, and (2) plastic tabs at the top of the bezel. NOTE: the air vent adjustment wheels stay on the dash.

STEP #2: Remove the 9/32"/7mm bolt from the top or bottom right side of radio. Place bottom part of mount over screw hole and replace screw. *If radio tab is in the way, you may need to clip it off, And/or remove rubber bumper.*

STEP #3: Insert the part 75001 (w/studs) into the Bottom Part so that you can read the logo and part number left to right. Install the (2) cap nuts supplied and tighten with the 5/16" open end wrench.

### Start Here for Chevy Traverse13-17, GMC Acadia13-16(Ltd17), Buick Enclave13-17

STEP #1: With your hands or Dash Tool, pull at the side of the radio/climate control bezel to release all clips, and set aside. Climate Controls are included with bezel.

STEP #2: Remove the 9/32"/7mm bolt from the top or bottom right side of radio. Place bottom part of mount over screw hole and replace screw. *This mount can also fit on the lower right radio screw with the small tab at the mounting screw flange removed. Modified mount part also fits on upper left side radio with optional 75002 Top Mount. (Enclave) Call for info.*

STEP #3: Insert the part 75001 (w/studs) into the Bottom Part so that you can read the logo and part number

NOTE: All models will fit in lower 2nd location if desired.



Chevy Traverse Install 09-12



Chevy Traverse 13-16 Install  
in Lower Location



Buick Enclave 13-16 Install



GMC Acadia 13-16 Install  
in lower location

01-30-19

